



NOTES:

1. DO NOT ATTACH LATH OR TRIMS THAT WILL BIND DEFLECTION
2. THERE ARE PROPRIETARY FLOOR LINE FLASHINGS & FLASHING SYSTEMS THAT ALLOW FOR DRAINAGE & DEFLECTION
3. Z-CHANNEL FURRING IS RECOMMENDED FOR RIGID FOAM THICKNESSES GREATER THAN 2"

## WEEP/ EXPANSION JOINT @ FLOOR LINE

PWA-104 (REV. 12/10)